

BIG BIKE PARTS® INSTALLATION INSTRUCTIONS

Copyright© 2002 by Big Bike Parts, Inc.
No part of this instruction sheet may be
reproduced without the written permission
of Big Bike Parts, Inc.©

TRUNK HANDLE

PART NO. 52-653

HONDA GL1800 GOLDWING

Revised 8/20/09

ITEMS REQUIRED: 4MM ALLEN WRENCH
PHILLIPS SCREWDRIVER
AWL MEASURING TAPE

INSTALLATION:

1. USING PHILLIPS SCREWDRIVER REMOVE THE SCREWS (1A) HOLDING THE INNER TRUNK LINER (1B) TO THE TRUNK LID (1C).
2. REMOVE THE INNER TRUNK LINER (1B).
3. MEASURE AND MARK THE CENTER OF THE HOLES WITH THE AWL. USE THE TRUNK HANDLE TO OBTAIN THE CORRECT MEASUREMENTS.
4. DRILL THE HOLES OUT USING A ¼" DRILL BIT.
5. INSTALL THE TRUNK HANDLE ON BIKE USING THE RUBBER PAD IN BETWEEN THE TRUNK LID (1C) AND TRUNK HANDLE. USE THE SCREWS, METAL WASHER AND RUBBER WASHER ON THE INSIDE OF TRUNK.
6. REINSTALL THE INNER TRUNK LINER (1B).

