

BIG BIKE PARTS® INSTALLATION INSTRUCTIONS

Copyright© 2003 by Big Bike Parts, Inc.™ No part of this instruction sheet may be reproduced without the written permission of Big Bike Parts, Inc.™

PART NO. 55-127 CHROME DRIVE
SHAFT COVER
HONDA VTX1800 & 1300

Revised 6/24/04

INSTALLATION:

1. CLEAN THE SURFACE OF THE DRIVE SHAFT.
2. THE COVER SLIDES ON AND THE BIG END GOES TO THE BACK OF THE DRIVE SHAFT AS CLOSE TO THE BACK AS POSSIBLE.
3. PEEL THE BACKING OFF THE ADHESIVE TAPE AND PLACE THE COVER ON THE BIKE.