

# **BIG BIKE PARTS®** INSTALLATION INSTRUCTIONS

## **DRIVE SHAFT BOLT TRIM**

Copyright © 2005 by Big Bike Parts, Inc.  
No part of this instruction sheet may be reproduced without the written permission of Big Bike Parts, Inc.

**PART NO. 55-134**

**TOOLS NEEDED: 3MM ALLEN WRENCH**

- 1. PUT M6 X 1.00 X 12MM LONG SOCKET HEAD SET SCREWS INTO PART.**
- 2. ALIGN CUTOUTS WITH THE BOLTS ON THE DRIVE SHAFT HOUSING.**
- 3. STARTING WITH THE BOTTOM SET SCREW, TIGHTEN UNTIL SNUG. THEN TIGHTEN THE TOP SET SCREW UNTIL SNUG.**

**NOTE: WE RECOMMEND USING LOC-TITE ON ALL SCREWS**