

BIG BIKE PARTS® INSTALLATION INSTRUCTIONS

Copyright© 2004 by Big Bike Parts, Inc.® No part of this instruction sheet may be reproduced without the written permission of Big Bike Parts, Inc.®

TWISTED CRUISER
MIRRORS
PART NO. 28-601 & 28-602

10MM REVERSE
MOUNT FOR
YAMAHA
CRUISERS

REVISED 04-07-09

TOOLS REQUIRED: 17MM WRENCH

NOTE: THE RIGHT SIDE MIRROR IS A LEFT HAND THREAD. THE NUTS WILL HAVE TO BE TURNED IN THE OPPOSITE DIRECTION OF THE LEFT SIDE.

INSTALLATION:

1. USING THE 17MM WRENCH LOOSEN THE NUT THAT HOLDS THE MIRRORS ON. SPIN THE WHOLE MIRROR ASSEMBLY TO TAKE IT OFF.
2. THREAD THE NEW MIRRORS INTO THE BIKE. DO NOT TIGHTEN.
3. POSITION THE MIRRORS INTO THE DESIRED POSITION FOR VIEWING COMFORT.
4. ONCE MIRRORS ARE IN THE DESIRED POSITION, TIGHTEN THE 17MM NUT THAT HOLDS THE MIRROR STEMS IN PLACE. TIGHTEN THE 14MM NUT ON THE BACK OF THE MIRROR TO HOLD THE BALL MOUNT TIGHT.

NOTE: WE RECOMMEND USING REMOVABLE LOC-TITE ON ALL THREADS