

Copyright© 2012 by Big Bike Parts, Inc. No part of this instruction sheet may be reproduced without the written permission of Big Bike Parts, Inc.

**PART NO. 41-156****3PC LID NET SET-TRUNK  
AND SADDLEBAG  
CAN-AM SPYDER RT**

12/6/2012

**TOOLS NEEDED:** TORX T20 DRIVER

PLEASE READ THROUGH AND UNDERSTAND THESE INSTRUCTIONS BEFORE BEGINNING.

**SECTION ONE – INSTALLING TRUNK LID NET**

1. USING THE T20 TORX DRIVER REMOVE THE 4 SCREWS AS SHOWN IN FIG. 1
2. REINSTALL THE TORX SCREWS WITH THE PLASTIC MOUNTING CLIPS PROVIDED AS IF IT WERE A WASHER, LEAVING THE “S” HOOK HOLE POINTING IN TOWARD THE CENTER OF THE TRUNK LID. SEE FIG. 1
3. ATTACH ONE OF THE NETS FROM THE KIT TO THE MOUNTING CLIPS AS SHOWN IN FIG. 1

**SECTION TWO-INSTALLING SADDLEBAG LID NETS**

1. USING THE T20 TORX DRIVER REMOVE THE 4 SCREWS AS SHOWN IN FIG. 2
2. REINSTALL THE TORX SCREWS WITH THE PLASTIC MOUNTING CLIPS PROVIDED AS IF IT WERE A WASHER, LEAVING THE “S” HOOK HOLE POINTING IN TOWARD THE CENTER OF THE SADDLEBAG LID. SEE FIG. 2
3. ATTACH ONE OF THE NETS FROM THE KIT TO THE MOUNTING CLIPS AS SHOWN IN FIG. 2
4. REPEAT ON OTHER SADDLEBAG.

**FIG. 1****FIG. 2**

Scan code  
with your  
smartphone to  
view video

