

BIG BIKE PARTS® INSTALLATION INSTRUCTIONS

Copyright© 2008 by Big Bike Parts, Inc. No part of this instruction sheet may be reproduced without the written permission of Big Bike Parts, Inc.

PART NO. 52-791

MARTINI TRUNK LIGHT SET
HONDA GL1800 GOLDWING

9/11/08

TOOLS NEEDED: PHILLIPS SCREWDRIVER AND 8MM SOCKET

NOTE: READ INSTRUCTIONS BEFORE PROCEEDING.

INSTALLATION:

1. PLACE BIKE ON CENTER STAND.
2. DISCONNECT THE NEGATIVE BATTERY CABLE.
3. REMOVE THE TWO SCREWS (1A) THAT HOLD THE RIGHT SIDE TRUNK MOLDING (1B) ON.
4. REMOVE THE TWO SCREWS (1C) THAT HOLD THE LEFT SIDE TRUNK MOLDING (1D) ON.
5. REMOVE THE TWO SCREWS (1E) THAT HOLD THE CENTER TRUNK MOLDING (1F) ON.
6. REMOVE THE FOUR SCREWS (1G) ON THE INSIDE OF THE TRUNK AND THE THREE SCREWS (1H) ON THE OUTSIDE OF THE TRUNK THAT HOLD THE UNDER TRUNK COVER (1J) ON. REMOVE THE UNDER TRUNK COVER.
7. USING THE 8MM SOCKET WRENCH REMOVE THE THREE ACORN NUTS IN THE TRUNK THAT HOLD EACH TRUNK LIGHT IN. THIS WILL ALLOW YOU TO PLUG INTO THE WIRES. THERE IS A HOLE IN THE BOTTOM OF THE TRUNK CAVITY TO ALLOW YOU TO RUN THE WIRES AND PLUG INTO THEM.
8. PLUG THE THREE PIN HARNESS BETWEEN THE BULB SOCKET AND THE OEM PLUG.
9. ATTACH THE CENTER, LEFT, AND RIGHT LIGHTS INTO THE BIKE HARNESS. THERE IS A LEFT AND RIGHT AND THEY ARE MARKED WITH "L" AND "R".
10. CHECK LIGHTS TO MAKE SURE THEY ALL WORK PROPERLY.
11. REINSTALL THE UNDER TRUNK COVER (1J) IN THE REVERSE OF REMOVAL. MAKE SURE THAT THE BLUE PLUGS ARE UNDERNEATH THE TRUNK SO THEY DON'T INTERFERE WITH THE UNDER TRUNK COVER (1J).
12. INSTALL THE NEW MOLDINGS IN THE REVERSE ORDER OF REMOVAL

