

4/16/2012

PARTS LIST:

CHROME GRILLE (1) M6-1 X 30MM BUTTON SOCKET HEAD CAP SCREW (2) M6 FLAT WASHER (2)

PREPARATION:

PARK THE BIKE ON A LEVEL SURFACE, TURN THE ENGINE OFF AND SHIFT THE TRANSMISSION INTO GEAR TO PREVENT THE BIKE FROM ROLLING. TURN THE HANDLEBARS TO THE LEFT TO PROVIDE ADEQUATE ROOM TO ACCESS THE RADIATOR GRILLE. MAKE CERTAIN THE RADIATOR HAS COOLED BEFORE PROCEEDING.

REMOVAL OF THE OEM GRILLE:

TOOLS REQUIRED: 5MM ALLEN WRENCH

1. USE THE 5MM ALLEN WRENCH TO REMOVE THE TWO SCREWS ON THE LOWER HALF OF THE GRILLE.
2. SLIDE THE GRILLE UPWARDS UNTIL THE MOUNTING HOOKS ON THE SIDES OF THE UPPER HALF OF THE GRILLE HAVE CLEARED THE RUBBER MOUNTS ON THE SIDES OF THE UPPER RADIATOR.
3. PULL THE GRILLE FORWARD TO REMOVE IT FROM THE MOTORCYCLE.
4. INSPECT THE RADIATOR AND REMOVE ANY DIRT OR DEBRIS BEFORE PROCEEDING WITH THE CHROME GRILLE INSTALLATION.

INSTALLATION OF THE BIG BIKE PARTS CHROME RADIATOR GRILLE:

TOOLS REQUIRED: 5MM ALLEN WRENCH, THREAD LOCKING COMPOUND

1. POSITION THE CHROME GRILLE OVER THE RADIATOR. MAKE SURE THE MOUNTING HOOKS ON THE GRILLE ARE DIRECTLY ABOVE THE RUBBER MOUNTS AT THE TOP OF THE RADIATOR.
2. SLIDE THE GRILLE DOWNWARDS UNTIL THE MOUNTING HOOKS ON THE TOP OF THE GRILLE ARE ENGAGED ON THE RUBBER RADIATOR MOUNTS.
3. APPLY THREAD LOCKING COMPOUND TO THE M6-1 X 30MM BUTTON SOCKET HEAD CAP SCREWS AND INSTALL THEM WITH A WASHER IN EACH OF THE TWO LOWER MOUNTING HOLES ON THE GRILLE. TIGHTEN SECURELY WITH THE 5MM ALLEN WRENCH.
4. TO REMOVE THE GRILLE FOR SERVICE, FOLLOW THE REMOVAL PROCEDURES LISTED ABOVE FOR THE OEM GRILLE.

