

PART NO. 63-203P LIGHT BAR MOUNTING BRACKET YAMAHA V-STAR 1300

8/19/2009

TOOLS NEEDED: 5MM ALLEN WRENCH 4MM WRENCH

NOTE: WE RECOMMEND USING THREADLOCKER ON ALL HARDWARE INSTALLED.
NOTE: READ INSTRUCTIONS BEFORE PROCEEDING.

INSTALLATION:

1. COVER FENDER TO PROTECT FROM SCRATCHING OR POSSIBLY DROPPING TOOLS.
2. USE THE 5MM ALLEN WRENCH, REMOVE THE (2) M8-1.25 X 16MM LONG BUTTON SOCKET HEAD CAP SCREWS (B) AND REMOVE EXISTING LIGHT BAR. DISCONNECT ALL WIRES GOING TO THE LIGHT BAR AT THIS TIME. RETAIN THE SCREWS FOR USE WITH THE REMAINING INSTALLATION.
3. PLACE THE NEW LIGHT BAR MOUNTING BRACKET (A) BETWEEN THE EXISTING LIGHT MOUNTING BRACKET HOLES(E) AND THE TRIPLE TREE SURFACE , ALIGN THE MOUNTING HOLES, AND SECURE WITH THE (2) M8-1.25 X 16MM LONG BUTTON SOCKET HEAD CAP SCREWS (B) FROM STEP #2. TIGHTEN IN PLACE WITH THE 5MM ALLEN WRENCH.
4. THE (3) M6-1.0 X 16MM LONG BUTTON SOCKET HEAD CAP SCREWS(C) AND (3) M6 LOCK WASHERS (D) WILL BE USED TO MOUNT THE NEW BBP LIGHT BAR (F).

