

BIG BIKE PARTS® INSTALLATION INSTRUCTIONS

Copyright© 2009 by Big Bike Parts, Inc. No part of this instruction sheet may be reproduced without the written permission of Big Bike Parts, Inc.

PART NO. 63-213

RESERVOIR
COVER

YAMAHA V-STAR 950

2/19/2010

TOOLS NEEDED: 4MM ALLEN WRENCH

HARDWARE INCLUDED: (1) STAINLESS STEEL M6 FLAT WASHER

WE RECOMMEND USING THREAD LOCKER ON ALL HARDWARE

INSTALLATION INSTRUCTIONS:

1. WITH THE 4MM ALLEN WRENCH, REMOVE THE EXISTING M6-1.0 X 20MM LONG BUTTON SOCKET HEAD CAP SCREW (A) AND THE EXISTING WASHER THAT ARE HOLDING THE EXISTING RESERVOIR COVER IN PLACE. RETAIN THE SCREW FOR USE IN STEP 2.

2. REPLACE THE EXISTING RESERVOIR COVER AND WASHER WITH THE NEW BBP CHROME RESERVOIR COVER (B) AND STAINLESS STEEL M6 FLAT WASHER (C) AND SCREW THEM IN PLACE WITH THE ORIGINAL M6-1.0 X 20MM LONG BUTTON SOCKET HEAD CAP SCREW (A) USING THE 4MM ALLEN WRENCH.

