

**BIG BIKE PARTS®**

Copyright © 2012 by Big Bike Parts, Inc. No part of this instruction sheet may be reproduced without the written permission of Big Bike Parts, Inc.

# INSTALLATION INSTRUCTIONS

PART NO. 71-203

LED TURNSIGNAL SPEAKER GRILLES

FOR KAWASAKI VN1700 VAQUERO &amp; VOYAGER

4/3/2012

TOOLS NEEDED:

4MM ALLEN WRENCH

8MM WRENCH

PHILLIPS SCREWDRIVER

**NOTE: THREAD LOCK COMPOUND SHOULD BE USED ON ALL HARDWARE****PLEASE READ THROUGH AND UNDERSTAND THESE INSTRUCTIONS BEFORE BEGINNING.****INSTRUCTIONS:**

1. REMOVE THE OEM SPEAKER TRIMS BY REMOVING THE 2 BUTTON HEAD ALLEN SCREWS, LEFT AND RIGHT SIDES.
2. REMOVE THE OEM MESH SPEAKER GRILLES BY BENDING THE 4 TABS ON THE BACK OF THE OEM SPEAKER TRIMS UP, REMOVE SPEAKER GRILLE, PLACE IN NEW LED TURNSIGNAL SPEAKER TRIM AND BEND TABS OVER TO SECURE.
3. REMOVE LEFT AND RIGHT SPEAKERS BY REMOVING THE 4 PHILLIP HEAD SCREWS. UNPLUG SPEAKERS AND SET ASIDE.
4. REMOVE SPEAKER HOUSING, LEFT AND RIGHT SIDES, AND SET ASIDE.
5. REMOVE ALLEN SCREW ON THE BOTTOM OF THE HEADLIGHT COWL. GENTLY PULL OUT BOTTOM OF COWL AND AT THE SAME TIME PULL OUT TOP LEFT THEN TOP RIGHT. COWL IS HELD IN BY 2 PINS ON TOP OF COWL GOING INTO GROMMETS.
6. USING A 8MM WRENCH REMOVE THE 4 BOLTS HOLDING THE HEADLIGHT IN. UNPLUG AND REMOVE HEADLIGHT.
7. LOCATE THE OEM LEFT AND RIGHT PLUG-N-PLAY TURNSIGNAL CONNECTIONS. THE OEM CONNECTORS LOOK THE SAME AS YOUR NEW LED TRIM CONNECTORS. OEM LEFT TURNSIGNAL IS BLACK PLUG-N-PLAY CONNECTOR. OEM RIGHT TURNSIGNAL IS A GRAY CONNECTOR.
8. INSERT THE WIRE FROM YOUR NEW RIGHT SIDE LED TURNSIGNAL THROUGH THE HOLE IN THE BOTTOM OF THE SPEAKER HOUSING AND FEED IT TO THE OEM TURNSIGNAL HARNESS. UNPLUG THE OEM CONNECTOR AND PLUG YOUR NEW CONNECTOR INTO THE OEMS. REPEAT FOR LEFT SIDE.

**NOTE: SPEAKER WIRES AND LED TRIM WIRE WILL FIT THROUGH HOLE IN BOTTOM OF SPEAKER HOUSING.**

9. TEST LEFT AND RIGHT SIDE LED TURNSIGNALS BEFORE YOU REASSEMBLE THE BIKE.

