

**BIG BIKE PARTS®**

Copyright© 2005 by Big Bike Parts, Inc.® No part of this instruction sheet may be reproduced without the written permission of Big Bike Parts Inc.®

## **INSTALLATION INSTRUCTIONS**

**REAR BRAKE CALIPER  
PART # 81-107**

**SUZUKI VZ1600 / M95 04-05  
KAWASAKI VN1600 04-05  
VN 1500 L2-L6 01-05**

**TOOLS NEEDED: 8MM ALLEN WRENCH**

**INSTALLATION:**

1. USING 8MM ALLEN WRENCH, REMOVE THE ALLEN HEAD BOLT AT THE FRONT OF CALIPER.
2. INSTALL THE NEW CALIPER COVER USING M10 X 1.25 X 25MM LONG SOCKET HEAD BOLTS PROVIDED AND SPACERS ON THE INSIDE OF BOLT HOLES WHERE THE BOLTS WERE REMOVED.

**NOTE: WE RECOMMEND USING LOC-TITE ON BOLTS.**