

## INSTALLATION INSTRUCTIONS

PART NO. 82-227B

SWITCH BOX BRAKE SIDE  
FOR SUZUKI C50/C90 2005-2006

Revised 6/24/09

TOOLS NEEDED: #1 PHILLIPS HEAD SCREWDRIVER    FLAT BLADE SCREW DRIVER    3MM ALLEN WRENCH  
#2 PHILLIPS HEAD SCREWDRIVER    NEEDLE NOSE PLIERS

1. LOOSEN CLUTCH CABLE TO GIVE YOURSELF AS MUCH SLACK AS POSSIBLE.
2. USING A 3MM ALLEN WRENCH REMOVE THE SCREW HOLDING THE PLATE TO THE BACK HALF OF THE OEM SWITCH BOX.
3. WITH A #2 PHILLIPS HEAD SCREWDRIVER REMOVE THE TWO SCREWS FROM THE BACK OF THE SWITCH BOX ALLOWING THE TWO HALVES TO BE SEPARATED.
4. WITH THE TWO HALVES SPLIT APART REMOVE THE THROTTLE CABLES FROM THE THROTTLE TUBE USING NEEDLE NOSE PLIERS IF NECESSARY.
5. USING A #1 PHILLIPS HEAD SCREWDRIVER REMOVE THE SCREW IN THE METAL TAB WHICH HOLDS THE WIRES TO THE SWITCH BOX. REMOVE THE SCREW WITH WASHER HOLDING THE START BUTTON BACKER. NEXT, REMOVE THE TWO SCREWS HOLDING THE BLACK PLASTIC COVER. REMOVE THE HAZARD SWITCH AND WITH A FLAT BLADE SCREWDRIVER REMOVE THE CLIP FROM THE BACKSIDE OF THE HAZARD BUTTON. FINALLY, REMOVE THE SCREW HOLDING THE KILL SWITCH IN PLACE.
6. INSTALL COMPONENTS REMOVED FROM THE OEM SWITCH BOX IN STEP #4 INTO CHROME SWITCH BOX IN REVERSE ORDER AS REMOVED. WHEN INSTALLING THE KILL SWITCH BE SURE TO PUSH IN THE BLACK PROTRUSION ON THE SIDE OF THE SWITCH SO THE KILL SWITCH CAN COMPLETELY SEAT IN THE SWITCH BOX.
7. REATTACH THE THROTTLE CABLES TO THE THROTTLE TUBE IN REVERSE ORDER AS STEP #4.
8. WITH A 3MM ALLEN WRENCH INSTALL THE SCREW AND PLATE INTO THE BACK HALF OF CHROME SWITCHBOX.
9. WITH A #2 PHILLIPS HEAD SCREWDRIVER REINSTALL THE TWO SCREWS REMOVED IN STEP #3.
10. READJUST THE THROTTLE CABLES TO YOUR PREFERRED TENSION.