

# BIG BIKE PARTS® INSTALLATION INSTRUCTIONS

Copyright© 2007 by Big Bike Parts, Inc. No part of this instruction sheet may be reproduced without the written permission of Big Bike Parts, Inc.

PART NO. 82-228

SISSY BAR BACKREST SET  
SUZUKI VL800 / C50 BOULEVARD

08/23/07

TOOLS NEEDED: 5MM ALLEN WRENCH 6MM ALLEN WRENCH 1/8" ALLEN WRENCH  
13MM WRENCH 12MM WRENCH THREADLOCKER

**NOTE: WE RECOMMEND USING THREADLOCKER ON ALL HARDWARE INSTALLED.**

1. USING THE 6MM ALLEN WRENCH, REMOVE THE FRONT BOLT FOR THE LEFT REAR FENDER CHROME TRIM AND INSTALL THE FRONT OF THE LEFT MOUNTING BRACKET (A) TO THE BIKE USING THE SUPPLIED M8-1.25 X 65MM LONG CAP SCREW (B). DO NOT TIGHTEN DOWN ALL THE WAY.
2. USING THE 6MM ALLEN WRENCH AND 12MM WRENCH TO HOLD THE NUT ON THE INSIDE OF FENDER. REMOVE THE REAR BOLT FOR THE LEFT REAR FENDER CHROME TRIM AND ROTATE THE BRACKET (A) SO YOU CAN INSTALL THE REAR M8-1.25 X 65MM LONG CAP SCREW (B). DO NOT TIGHTEN DOWN ALL THE WAY.

**NOTE: IF YOU HAVE SHOW CHROME SADDLEBAG STAYS (PART# 82-209 (C)) INSTALLED, YOU WILL NEED TO USE THE M8-1.25 X 95MM LONG CAP SCREWS (B) SUPPLIED. THE SADDLEBAG STAY WILL GO BETWEEN THE MOUNTING BRACKET (A) AND THE HEAD OF THE M8-1.25 X 95MM LONG CAP SCREW (B).**

3. REPEAT STEPS 1 AND 2 FOR THE RIGHT SIDE.
4. FASTEN THE SISSY PAD (D) TO THE BACKREST BAR (F) USING THE 1/8" ALLEN WRENCH AND THE THREE 10-32 X 1.0" LONG COUNTERSUNK CAP SCREWS (E). MAKE SURE THE SISSY PAD IS ON THE OPPOSITE FACE THE THREE COUNTERSUNK HOLES ARE ON.
5. SLIDE THE BACKREST BAR WITH THE PAD INTO THE BRACKETS AND LINE UP THE HOLES. THEN SLIDE THE FOUR M8-1.25 X 30MM LONG CAP SCREWS (G) IN AND TIGHTEN DOWN WITH THE FOUR M8-1.25 ACORN NUTS (H) SUPPLIED USING A 5MM ALLEN WRENCH AND THE 13MM WRENCH.

**NOTE: IF YOU ARE ALSO INSTALLING SHOW CHROME SISSY BAR RACK (PART# 55-322 (J)) YOU WILL USE THE FOUR M8-1.25 X 35MM LONG CAP SCREWS (G) SUPPLIED WITH THE RACK.**

6. TIGHTEN DOWN THE REMAINING FOUR BOLTS (B) HOLDING THE MOUNTING BRACKETS TO THE BIKE.

