

Copyright © 2022 by Big Bike Parts, Inc. No part of this instruction sheet may be reproduced without the written permission of Big Bike Parts, Inc.

PART NO. H44-3BK, H44-3RED, H44-3BLUE, H44-3ZRED, H44-3ZBLUE

CONSOLE ORGANIZER

7/28/2022

FITMENT: POLARIS SLINGSHOT 2015-NEWER

TOOLS NEEDED: T40 TORX

RUBBING ALCOHOL

LINT FREE RAG

PLEASE READ THROUGH AND UNDERSTAND THESE INSTRUCTIONS BEFORE BEGINNING.

ESTIMATED INSTALLATION TIME: 5 TO 10 MIN.

**INSTALLATION:**

1. REMOVE THE TWO SCREWS USING A T40 TORX (FIG. 1). THESE WILL BE RE-USED.
2. CLEAN THE TWO AREAS SHOWN IN FIG. 1 WITH RUBBING ALCOHOL AND A LINT FREE RAG. LET DRY COMPLETELY.
3. LOOKING AT THE BACK OF THE CONSOLE ORGANIZER, REMOVE THE BACKING FROM THE HOOK AND LOOP.
4. CAREFULLY SET THE CONSOLE ORGANIZER INTO PLACE MAKING SURE THE TWO HOLES LINE UP WITH THE SCREW HOLES AND APPLY PRESSURE TO ALL OF THE AREAS WITH THE HOOK AND LOOP (FIG. 2).
5. REINSTALL THE TWO SCREWS THAT WERE REMOVED IN STEP 1 TO SECURE THE TOP OF THE CONSOLE ORGANIZER (FIG. 2).
6. LET THE SLINGSHOT SIT FOR AT LEAST 24 HOURS FOR ADHESIVE TO CURE.



**NOTICE**

IGNORING THE CONTENTS OF THESE INSTRUCTIONS MAY AFFECT THE PRODUCT PERFORMANCE AND FUNCTIONALITY. NOT FOLLOWING THESE INSTRUCTIONS MAY CAUSE DAMAGE TO THE PRODUCT OR THE VEHICLE TO WHICH IT IS BEING ATTACHED.

**NOTICE**

THIS IS AN ADHESIVE BACKED PRODUCT. CAUTION MUST BE TAKEN DURING INSTALLATION TO PROPERLY POSITION FOR ONE TIME PLACEMENT. REPEAT TRIALS WILL RESULT IN FAILURE OF THE ADHESIVE.