



Copyright © 2022 by Big Bike Parts, Inc. No part of this instruction sheet may be reproduced without the written permission of Big Bike Parts, Inc.

# INSTALLATION INSTRUCTIONS

PART NO. H44-8BK/H44-8RED/H44-8BLU

DESCRIPTION: GLOVE BOX ORGANIZER

ESTIMATED INSTALLATION TIME: 10 TO 20 MIN

FITMENT: POLARIS SLINGSHOT 2015-NEWER

TOOLS NEEDED:	RUBBING ALCOHOL	CLEAN LINT FREE RAG		
INCLUDED:	GLOVE BOX ORGANIZER (1)	ADHESIVE LOOP STRIP (4)		

PLEASE READ THROUGH AND UNDERSTAND THESE INSTRUCTIONS BEFORE BEGINNING.

**INSTALLATION:**

1. OPEN THE GLOVE BOX AND REMOVE ANY ITEMS YOU MAY HAVE INSIDE.
2. CLEAN THE AREAS OF THE GLOVE BOX SHOWN IN FIG. 1 WITH RUBBING ALCOHOL AND A CLEAN LINT FREE RAG.
3. SET THE GLOVE BOX ORGANIZER INTO THE GLOVE BOX.
4. STARTING ON THE LEFT REAR SIDE OF THE GLOVE BOX ORGANIZER, CAREFULLY PEEL THE BACKER FROM THE LOOP STRIP ON THE OUTSIDE OF THE GLOVE BOX ORGANIZER (FIG. 2). WITH THE GLOVE BOX ORGANIZER IN POSITION, CAREFULLY PRESS THE ADHESIVE HOOK IN PLACE AGAINST THE GLOVE BOX. **BE SURE GLOVE BOX ORGANIZER STAYS IN POSITION WHEN ATTACHING.**
5. REPEAT STEP 4 ON THE RIGHT SIDE OF THE GLOVE BOX ORGANIZER TO SECURE THE RIGHT REAR SIDE OF THE GLOVE BOX ORGANIZER IN PLACE.
6. REMOVE THE BACKER FROM THE HOOK ON ONE OF THE FRONT TABS OF THE GLOVE BOX ORGANIZER. CAREFULLY PRESS INTO PLACE WHILE LINING UP THE EDGES OF THE FRONT TABS OF THE GLOVE BOX ORGANIZER WITH THE EDGES OF THE GLOVE BOX (FIG. 3).
7. REPEAT STEP 6 FOR THE OTHER FRONT TAB OF THE GLOVE BOX ORGANIZER.
8. LET THE GLOVE BOX ORGANIZER SIT FOR 24 HOURS FOR THE ADHESIVE TO CURE FULLY BEFORE USE.



**NOTICE**  
 THIS IS AN ADHESIVE BACKED PRODUCT. CAUTION MUST BE TAKEN DURING INSTALLATION TO PROPERLY POSITION FOR ONE TIME PLACEMENT. REPEAT TRIALS WILL RESULT IN FAILURE OF THE ADHESIVE.

**NOTICE**  
 IGNORING THE CONTENTS OF THESE INSTRUCTIONS MAY AFFECT THE PRODUCT PERFORMANCE AND FUNCTIONALITY. NOT FOLLOWING THESE INSTRUCTION MAY CAUSE DAMAGE TO THE PRODUCT OR THE VEHICLE TO WHICH IT IS BEING ATTACHED.