

# BIG BIKE PARTS® INSTALLATION INSTRUCTIONS

Copyright© 2012 by Big Bike Parts, Inc. No part of this instruction sheet may be reproduced without the written permission of Big Bike Parts, Inc.©

PART NO. 52-802

BUNGEE SEAT TIE-DOWN  
BRACKETS

FOR GL1500 & GL1800 Gold Wing: 1988-2017

Revised 11/29/2022

TOOLS REQUIRED: 6MM ALLEN WRENCH

INSTALLATION:

1. START BY REMOVING THE PASSENGER HANDLES FROM THE BIKE. TO REMOVE HANDLES, REMOVE THE TWO OEM BOLTS ON EACH SIDE OF THE BIKE USING 6MM ALLEN WRENCH.
2. ONCE OEM BOLTS ARE REMOVED, CAREFULLY PULL HANDLE FROM SEAT. BE AWARE THAT THE OEM BOLTS ARE NO LONGER SECURED AND MAY FALL OUT.
3. INSTALL BIG BIKE PARTS BUNGEE SEAT TIE-DOWN BRACKETS BETWEEN THE HANDLE AND SEAT, THEN POSITION OEM BOLT BACK THROUGH BOTH PIECES.
4. REATTACH HANDLE BACK TO SEAT BY FASTENING OEM BOLTS WITH THE BUNGEE SEAT TIE-DOWN BRACKETS ALIGNED AND IN PLACE.

TIE-

# BIG BIKE PARTS® INSTALLATION INSTRUCTIONS

Copyright© 2012 by Big Bike Parts, Inc. No part of this instruction sheet may be reproduced without the written permission of Big Bike Parts, Inc.©

PART NO. 52-802

BUNGEE SEAT TIE-DOWN  
BRACKETS

FOR GL1500 & GL1800 Gold Wing: 1988-2017

Revised 11/29/2022

TOOLS REQUIRED: 6MM ALLEN WRENCH

INSTALLATION:

1. START BY REMOVING THE PASSENGER HANDLES FROM THE BIKE. TO REMOVE HANDLES, REMOVE THE TWO OEM BOLTS ON EACH SIDE OF THE BIKE USING 6MM ALLEN WRENCH.
2. ONCE OEM BOLTS ARE REMOVED, CAREFULLY PULL HANDLE FROM SEAT. BE AWARE THAT THE OEM BOLTS ARE NO LONGER SECURED AND MAY FALL OUT.
3. INSTALL BIG BIKE PARTS BUNGEE SEAT TIE-DOWN BRACKETS BETWEEN THE HANDLE AND SEAT, THEN POSITION OEM BOLT BACK THROUGH BOTH PIECES.
4. REATTACH HANDLE BACK TO SEAT BY FASTENING OEM BOLTS WITH THE BUNGEE SEAT TIE-DOWN BRACKETS ALIGNED AND IN PLACE.

# BIG BIKE PARTS® INSTALLATION INSTRUCTIONS

Copyright© 2012 by Big Bike Parts, Inc. No part of this instruction sheet may be reproduced without the written permission of Big Bike Parts, Inc.©

PART NO. 52-802

BUNGEE SEAT TIE-DOWN  
BRACKETS

FOR GL1500 & GL1800 Gold Wing: 1988-2017

Revised 11/29/2022

TOOLS REQUIRED: 6MM ALLEN WRENCH

INSTALLATION:

1. START BY REMOVING THE PASSENGER HANDLES FROM THE BIKE. TO REMOVE HANDLES, REMOVE THE TWO OEM BOLTS ON EACH SIDE OF THE BIKE USING 6MM ALLEN WRENCH.
2. ONCE OEM BOLTS ARE REMOVED, CAREFULLY PULL HANDLE FROM SEAT. BE AWARE THAT THE OEM BOLTS ARE NO LONGER SECURED AND MAY FALL OUT.
3. INSTALL BIG BIKE PARTS BUNGEE SEAT TIE-DOWN BRACKETS BETWEEN THE HANDLE AND SEAT, THEN POSITION OEM BOLT BACK THROUGH BOTH PIECES.
4. REATTACH HANDLE BACK TO SEAT BY FASTENING OEM BOLTS WITH THE BUNGEE SEAT TIE-DOWN BRACKETS ALIGNED AND IN PLACE.