

Copyright © 2007 by Big Bike Parts, Inc. No part of this instruction sheet may be reproduced without the written permission of Big Bike Parts, Inc.

PART NO. 20-516, 20-516T,  
20-518, 20-518T

WINDSHIELD WITH VENT

10/12/2015

FITMENT: HONDA GOLDWING GL1800 2001-NEWER

TOOLS NEEDED: 8MM SOCKET WRENCH

10MM WRENCH

5MM ALLEN WRENCH

PHILLIPS SCREWDRIVER

**PLEASE READ THROUGH AND UNDERSTAND THESE INSTRUCTIONS BEFORE BEGINNING.**

**ESTIMATED INSTALLATION TIME: 20 TO 30 MIN.**

**INSTALLATION:**

1. TAKE THE VENT AND REMOVE THE TWO BOLT HOLDING THE FRONT AND BACK TOGETHER. SEE FIG. 1. NOTE THE POSITION OF THE PLASTIC WASHERS.
2. INSTALL THE VENT IN THE NEW WINDSHIELD BY INSERTING THE FRONT HALF INTO THE CUTOUT ON THE WINDSHIELD.
3. THEN INSTALL THE REAR HALF BY INSERTING THE TOP FIRST AND THEN SNAPPING THE BOTTOM TOGETHER.
4. INSTALL BOTH BOLTS MAKING SURE THE PLASTIC WASHER IS ON THE FRONT SIDE AND THE HEX NUT IS TO THE REAR. TIGHTEN.
5. TO REMOVE OLD WINDSHIELD FIRST RELEASE THE TWO HEIGHT LEVERS (2A) AND PULL BACK THE RUBBER MIRROR COVERS (2B). SEE FIG. 2.
6. TILT EACH MIRROR FORWARD AND USING A 10MM WRENCH REMOVE THE TWO BOLTS AND WASHERS (3A, 3B, 3C) HOLDING THE WINDSHIELD GARNISH (3D) TO THE BIKE. SEE FIG. 3.
7. LIFT THE WINDSHIELD GARNISH AND PULL IT FORWARD TO REMOVE IT.
8. ROTATE THE BLACK PLASTIC COVER (4A) AS SHOWN IN FIG. 4. THEN USING AN 8MM SOCKET REMOVE BOLT (4B) TO RELEASE THE WINDSHIELD CLAMP (4C).
9. LIFT THE WINDSHIELD CLAMP AND USING A 5MM ALLEN WRENCH AND A PHILLIPS SCREWDRIVER REMOVE THE FOUR SCREWS (5A) HOLDING THE WINDSHIELD TO THE BIKE. SEE FIG. 5.
10. REMOVE THE TWO OUTSIDE METAL CLIPS (5C) WITH THE SCREWS (5A).
11. REMOVE THE WINDSHIELD AND WITH A PHILLIPS SCREWDRIVER REMOVE SMALL SCREW (5B) AND THEN REMOVE THE CENTER CLIPS FROM THE WINDSHIELD.
12. INSTALL THE CENTER CLIPS ON THE NEW WINDSHIELD AND REINSTALL ALL THE PARTS YOU REMOVED IN REVERSE ORDER YOU REMOVED THEM.

