

BIG BIKE PARTS® INSTALLATION INSTRUCTIONS

CHROME MIRROR MOUNT COVERS

PART NO. 2-493

FITS ALL GL1500/6

GOLD WING MODELS

Copyright© 1998 by Big Bike Parts, Inc. No part of this instruction sheet may be reproduced without the written permission of Big Bike Parts, Inc.®

Revised 7/25/2017

TOOLS REQUIRED: #2 PHILLIPS SCREWDRIVER

INSTALLATION:

1. PLACE YOUR GOLD WING SECURELY ON ITS CENTER STAND
2. UNHOOK THE L/R RUBBER MIRROR GASKETS (1A) FROM THE MIRRORS (1B) AND MIRROR MOUNT COVERS (1C).
3. RELEASE THE L/R MIRROR COVER SPRING CLAMP (1D) FROM THE FAIRING LEDGE (1E) AND PIVOT THE MIRROR MOUNT COVERS (1C) SO AS TO EXPOSE THE THREE SCREWS (1F).
4. USING THE #2 MEDIUM PHILLIPS SCREWDRIVER, REMOVE THE THREE L/R SCREWS (1F) HOLDING THE MIRROR UNIT MOUNTING BRACKET IN PLACE.
NOTE: PIVOTING THE MIRROR UNIT (1B) BACK AND OUT OF THE WAY MAY GIVE BETTER ACCESS TO ALL SCREWS, BUT **DO NOT** PIVOT MIRROR UNIT IF ANY OF THE SCREWS HAVE ALREADY BEEN REMOVED AS THIS COULD PUT UNEVEN PRESSURE ON A SCREW MOUNTING HOLE THAT COULD CAUSE DAMAGE.
5. NOW WITH THE MIRROR UNITS DETACHED, USE THE #2 PHILLIPS SCREWDRIVER TO REMOVE THE SPRING CLAMP (1D) FROM THE L/R OEM MIRROR MOUNT COVERS.
6. USING THE EXISTING SPRING CLAMP SCREWS REMOUNT THE OEM SPRING CLAMP ONTO THE NEW CHROME MIRROR MOUNT COVERS.
7. REINSTALL THE MIRROR MOUNT COVER AND MIRRORS FOLLOWING INSTRUCTIONS 1 TO 4 ABOVE, IN REVERSE ORDER.

CARE: CLEAN ONLY WITH SOAP AND WATER, DO NOT USE ANY ABRASIVE CLEANERS.

