

Copyright © 2019 by Big Bike Parts, Inc. No part of this instruction sheet may be reproduced without the written permission of Big Bike Parts, Inc.

PART NO. 52-957

SADDLEBAG SCUFF TRIM SET

9/27/2019

FITMENT: HONDA GOLDWING/GOLDWING TOUR 2018-NEWER

TOOLS NEEDED: RUBBING ALCOHOL

LINT FREE TOWEL

MASKING TAPE

RULER

PLEASE READ THROUGH AND UNDERSTAND THESE INSTRUCTIONS BEFORE BEGINNING.**ESTIMATED INSTALLATION TIME: 15 TO 25 MIN.****INSTALLATION:**

1. USING RUBBING ALCOHOL AND A LINT FREE TOWEL CLEAN THE TOP AND THE FRONT OF THE RIGHT SADDLEBAG LID. LET DRY.
2. REMOVE THE FOUR SADDLEBAG SCUFFS FROM THE PACKAGE.
3. USING FIG. 1 AS A GUIDE, FIND THE RIGHT OUTSIDE SCUFF. USE THE TAPE REMOVAL TAB AS A REFERENCE.
4. USING FIG. 2 AS A GUIDE, FIND THE RIGHT INSIDE SCUFF.
5. CUT 10 PIECES OF MASKING TAPE ABOUT 3/4" X 3/4".
6. STARTING WITH THE RIGHT INSIDE SCUFF (FIG. 2) PLACE A PIECE OF MASKING TAPE ON EACH END OF THE SCUFF. SEE FIG. 3.
7. USING A RULER PLACE THE INSIDE SCUFF ON THE RIGHT SADDLEBAG LID AND TAPE IN PLACE AS SHOWN IN FIG. 3.
8. USING A RULER PLACE THE OUTSIDE SCUFF IN PLACE AS SHOWN IN FIG. 3.
9. WITH THE TWO SCUFFS TAPED INTO PLACE USE THE REMAINING SIX PIECES OF TAPE TO MARK THE SIDES OF EACH SCUFF AS SHOWN IN FIG. 4.
10. HOLD EACH SCUFF WITH YOUR HAND AND MOVE THE TOP PIECES OF MASKING TO MARK TOP OF THE SCUFFS.
11. REMOVE BOTH SCUFFS FROM THE SADDLEBAG LID.
12. STARTING WITH THE INSIDE SCUFF REMOVE THE MASKING FROM THE DOUBLE-SIDED TAPE.
13. USING THE MASKING AS MARKERS CAREFULLY PLACE THE INSIDE SCUFF INTO PLACE.
14. STARTING FROM THE CENTER OF THE SCUFF APPLY PRESSURE TO THE SCUFF TO SET THE ADHESIVE TO THE LID.
15. REPEAT STEPS 12 AND 14 FOR THE OUTSIDE SCUFF.
16. REPEAT STEPS 1 THROUGH 15 FOR THE LEFT SADDLEBAG SCUFFS.
17. LET TAPE CURE FOR 24 HOURS BEFORE USING.

**NOTICE**

TEST FIT THIS ITEM TO THE MOUNTING SURFACE BEFORE REMOVING THE MASKING. IF NEEDED GENTLY SHAPE THE ITEM FOR THE BEST FIT BEFORE INSTALLING.

NOTICE

THIS IS AN ADHESIVE BACKED PRODUCT. CAUTION MUST BE TAKEN DURING INSTALLATION TO PROPERLY POSITION FOR ONE TIME PLACEMENT. REPEAT TRIALS WILL RESULT IN FAILURE OF THE ADHESIVE.

NOTICE

IGNORING THE CONTENTS OF THESE INSTRUCTIONS MAY AFFECT THE PRODUCT PERFORMANCE AND FUNCTIONALITY. NOT FOLLOWING THESE INSTRUCTION MAY CAUSE DAMAGE TO THE PRODUCT OR THE VEHICLE TO WHICH IT IS BEING ATTACHED.