

BIG BIKE PARTS[®]

Copyright[®] 2013 by Big Bike Parts, Inc. No part of this instruction sheet may be reproduced without the written permission of Big Bike Parts, Inc.

INSTALLATION INSTRUCTIONS

PART NO. H40-404BK

GLOVE BOX ORGANIZER

FOR CAN-AM RYKER

3/12/2020

TOOLS NEEDED: RUBBING ALCOHOL

LINT FREE RAG

NOTE: ALWAYS ALLOW 24 HOURS FOR TAPE ADHESIVE TO CURE BEFORE USING.

PLEASE READ THROUGH AND UNDERSTAND THESE INSTRUCTIONS BEFORE BEGINNING.

INSTALLATION

1. TEST FIT THE GLOVE BOX ORGANIZER ON THE GLOVE BOX LID NOTING THAT IT ALIGNS CENTERED ON THE GLOVE BOX LID.
2. REMOVE THE GLOVE BOX ORGANIZER AND USE A LINT FREE RAG AND SOME RUBBING ALCOHOL TO CLEAN THE GLOVE BOX LID AREA WHERE THE GLOVE BOX ORGANIZER IS BEING INSTALLED, LET DRY COMPLETELY.
3. LOOKING AT THE BACK SIDE OF THE GLOVE BOX ORGANIZER, REMOVE THE BACKING FROM THE HOOK AND LOOP.
4. SET THE GLOVE BOX ORGANIZER INTO PLACE AND APPLY PRESSURE TO ALL OF THE AREAS WITH THE HOOK AND LOOP.
5. LET THE RYKER SIT FOR AT LEAST 24 HOURS FOR TAPE ADHESIVE TO CURE.
6. REMOVE THE GLOVE BOX ORGANIZER BY SEPARATING HOOK AND LOOP.
7. CHECK TO MAKE SURE THAT ALL OF THE PIECES OF HOOK TAPE HAVE ADHERED TO THE GLOVE BOX LID FULLY. APPLY PRESSURE TO ANY LOOSE AREAS.
8. REATTACH THE GLOVE BOX ORGANIZER.

Scan code with
your smartphone
to view video



BIG BIKE PARTS[®]

Copyright[®] 2013 by Big Bike Parts, Inc. No part of this instruction sheet may be reproduced without the written permission of Big Bike Parts, Inc.

INSTALLATION INSTRUCTIONS

PART NO. H40-404BK

GLOVE BOX ORGANIZER

FOR CAN-AM RYKER

3/12/2020

TOOLS NEEDED: RUBBING ALCOHOL

LINT FREE RAG

NOTE: ALWAYS ALLOW 24 HOURS FOR TAPE ADHESIVE TO CURE BEFORE USING.

PLEASE READ THROUGH AND UNDERSTAND THESE INSTRUCTIONS BEFORE BEGINNING.

INSTALLATION

1. TEST FIT THE GLOVE BOX ORGANIZER ON THE GLOVE BOX LID NOTING THAT IT ALIGNS CENTERED ON THE GLOVE BOX LID.
2. REMOVE THE GLOVE BOX ORGANIZER AND USE A LINT FREE RAG AND SOME RUBBING ALCOHOL TO CLEAN THE GLOVE BOX LID AREA WHERE THE GLOVE BOX ORGANIZER IS BEING INSTALLED, LET DRY COMPLETELY.
3. LOOKING AT THE BACK SIDE OF THE GLOVE BOX ORGANIZER, REMOVE THE BACKING FROM THE HOOK AND LOOP.
4. SET THE GLOVE BOX ORGANIZER INTO PLACE AND APPLY PRESSURE TO ALL OF THE AREAS WITH THE HOOK AND LOOP.
5. LET THE RYKER SIT FOR AT LEAST 24 HOURS FOR TAPE ADHESIVE TO CURE.
6. REMOVE THE GLOVE BOX ORGANIZER BY SEPARATING HOOK AND LOOP.
7. CHECK TO MAKE SURE THAT ALL OF THE PIECES OF HOOK TAPE HAVE ADHERED TO THE GLOVE BOX LID FULLY. APPLY PRESSURE TO ANY LOOSE AREAS.
8. REATTACH THE GLOVE BOX ORGANIZER.

Scan code with
your smartphone
to view video

