BIG BIKE PARTS

 ${\sf Copyright}^{ \hbox{\it CO}} \ 2021 \ by \ {\sf Big} \ {\sf Bike} \ {\sf Parts}, \ {\sf Inc.} \ {\sf No} \ {\sf part} \ {\sf of} \ {\sf this} \\ {\sf instruction} \ {\sf sheet} \ {\sf may} \ {\sf be} \ {\sf reproduced} \ {\sf without} \ {\sf the} \ {\sf written} \\ {\sf permission} \ {\sf of} \ {\sf Big} \ {\sf Bike} \ {\sf Parts}, \ {\sf Inc.} \\ \\$

INSTALLATION INSTRUCTIONS

PART NO. HG18TO

TRUNK ORGANIZER SET

FITMENT:

GOLDWING TOUR 2018-NEWER

TOOLS NEEDED: PHILLIPS SCREWDRIVER

RUBBING ALCOHOL LINT FREE TOWEL

PLEASE READ THROUGH AND UNDERSTAND THESE INSTRUCTIONS BEFORE BEGINNING.

ESTIMATED INSTALLATION TIME: 15 TO 20 MIN.

INSTALLATION:

REVISED 2/23/2021

- 1. USING FIG. 1 REMOVE THE LEFT ORGANIZER FROM THE PACKAGING.
- 2. OPEN THE TRUNK ON THE BIKE.
- 3. ON THE LEFT SIDE OF THE TRUNK USE A PHILLIPS SCREWDRIVER TO REMOVE THE TWO SCREWS SHOWN IN FIG. 2.
- 4. USING RUBBING ALCOHOL AND CLEAN LINT FREE TOWEL CLEAN THE AREAS SHOWN IN FIG. 2. LET DRY.
- 5. USING THE SCREWS YOU REMOVED IN STEP 3 INSTALL THE LEFT SIDE ORGANIZER AS SHOWN IN FIG. 3. TIGHTEN BOTH SCREWS.
- STARTING WITH THE BOTTOM, LIFT THE ORGANIZER AS SHOWN IN FIG. 4 AND REMOVE THE CLEAR FILM FROM THE HOOK.
- 7. PUT THE BOTTOM OF THE ORGANIZER BACK IN PLACE AND PRESS FIRMLY DOWN IN THE AREA OF THE HOOK AND LOOP (FIG. 4 SHOWS HOOK IN PLACE AFTER INSTALLED).
- 8. REPEAT STEPS 6 AND 7 BY PULLING BOTH THE FRONT AND BACK UPPER CORNER AREAS BACK AND ATTACHING THE SMALL PIECES OF HOOK.
- 9. REPEAT STEPS 3 TO 8 ON THE RIGHT SIDE ORGANIZER.
- 10. LET ADHESIVE CURE FOR 24 HOURS BEFORE USE.







