

<b>BIG BIKE PARTS®</b>		<b>INSTALLATION INSTRUCTIONS</b>	
Copyright© 2020 by Big Bike Parts, Inc. No part of this instruction sheet may be reproduced without the written permission of Big Bike Parts, Inc.		PART NO. H41-169BK & H41-169C	DASH POUCH LARGE
10/04/2023		FOR CAN-AM SPYDER RT 2020-NEWER	
TOOLS NEEDED:	RUBBING ALCOHOL	LINT FREE RAG	
<p><b>NOTE: ALWAYS ALLOW 24 HOURS FOR TAPE ADHESIVE TO CURE BEFORE USING.</b></p> <p>PLEASE READ THROUGH AND UNDERSTAND THESE INSTRUCTIONS BEFORE BEGINNING.</p> <p><b>INSTALLATION</b></p> <ol style="list-style-type: none"> <li>1. TEST FIT THE CENTER POUCH ON DASH BOARD NOTING THAT IT ALIGNS WITH THE EDGE NEAREST THE DRIVER AND CENTERED ON THE DASH BOARD.</li> <li>2. REMOVE THE POUCH AND USE A LINT FREE RAG AND SOME RUBBING ALCOHOL TO CLEAN THE DASH BOARD AREA WHERE THE DASH POUCH IS BEING INSTALLED, LET DRY COMPLETELY.</li> <li>3. LOOKING AT THE BOTTOM OF THE WINDSHIELD POUCH REMOVE THE BACKING FROM THE HOOK AND LOOP.</li> <li>4. CAREFULLY SET THE WINDSHIELD POUCH BACK INTO PLACE AND APPLY PRESSURE TO ALL OF THE AREAS WITH THE HOOK AND LOOP.</li> <li>5. LET THE SPYDER SIT FOR AT LEAST 24 HOURS FOR TAPE ADHESIVE TO CURE.</li> <li>6. REMOVE WINDSHIELD POUCH BY SEPARATING HOOK AND LOOP.</li> <li>7. CHECK TO MAKE SURE THAT ALL OF THE PIECES OF HOOK TAPE HAVE ADHERED TO THE DASH BOARD FULLY. APPLY PRESSURE TO ANY LOOSE AREAS.</li> <li>8. REATTACH THE WINDSHIELD POUCH.</li> </ol>			

<b>BIG BIKE PARTS®</b>		<b>INSTALLATION INSTRUCTIONS</b>	
Copyright© 2020 by Big Bike Parts, Inc. No part of this instruction sheet may be reproduced without the written permission of Big Bike Parts, Inc.		PART NO. H41-169BK & H41-169C	DASH POUCH LARGE
10/04/2023		FOR CAN-AM SPYDER RT 2020-NEWER	
TOOLS NEEDED:	RUBBING ALCOHOL	LINT FREE RAG	
<p><b>NOTE: ALWAYS ALLOW 24 HOURS FOR TAPE ADHESIVE TO CURE BEFORE USING.</b></p> <p>PLEASE READ THROUGH AND UNDERSTAND THESE INSTRUCTIONS BEFORE BEGINNING.</p> <p><b>INSTALLATION</b></p> <ol style="list-style-type: none"> <li>1. TEST FIT THE CENTER POUCH ON DASH BOARD NOTING THAT IT ALIGNS WITH THE EDGE NEAREST THE DRIVER AND CENTERED ON THE DASH BOARD.</li> <li>2. REMOVE THE POUCH AND USE A LINT FREE RAG AND SOME RUBBING ALCOHOL TO CLEAN THE DASH BOARD AREA WHERE THE DASH POUCH IS BEING INSTALLED, LET DRY COMPLETELY.</li> <li>3. LOOKING AT THE BOTTOM OF THE WINDSHIELD POUCH REMOVE THE BACKING FROM THE HOOK AND LOOP.</li> <li>4. CAREFULLY SET THE WINDSHIELD POUCH BACK INTO PLACE AND APPLY PRESSURE TO ALL OF THE AREAS WITH THE HOOK AND LOOP.</li> <li>5. LET THE SPYDER SIT FOR AT LEAST 24 HOURS FOR TAPE ADHESIVE TO CURE.</li> <li>6. REMOVE WINDSHIELD POUCH BY SEPARATING HOOK AND LOOP.</li> <li>7. CHECK TO MAKE SURE THAT ALL OF THE PIECES OF HOOK TAPE HAVE ADHERED TO THE DASH BOARD FULLY. APPLY PRESSURE TO ANY LOOSE AREAS.</li> <li>8. REATTACH THE WINDSHIELD POUCH.</li> </ol>			