

BIG BIKE PARTS® INSTALLATION INSTRUCTIONS

Copyright© 2004 by Big Bike Parts, Inc.® No part of this instruction sheet may be reproduced without the written permission of Big Bike Parts, Inc.®

**TWISTED CRUISER MIRROR
PART NO. 28-101 & 28-102**

**10MM MOUNT
FOR HONDA/
KAWASAKI/
SUZUKI
CRUISERS**

REVISED 04-02-09

TOOLS REQUIRED: 17MM WRENCH

INSTALLATION:

- 1. THREAD THE NEW MIRRORS INTO THE BIKE. DO NOT TIGHTEN.**
- 2. POSITION THE MIRRORS INTO THE DESIRED POSITION FOR VIEWING COMFORT.**
- 3. ONCE MIRRORS ARE IN THE DESIRED POSITION, TIGHTEN THE 17MM NUT THAT HOLDS THE MIRROR STEMS IN PLACE.**

NOTE: WE RECOMMEND USING REMOVABLE LOC-TITE ON ALL THREADS