

Copyright© 2001 by Big Bike Parts, Inc.
No part of this instruction sheet may be
reproduced without the written permission
of Big Bike Parts, Inc.©

Revised 2/12/2009

ITEMS REQUIRED: PHILLIPS SCREWDRIVER

INSTALLATION:

1. REMOVE THE TWO SCREWS (1A) THAT HOLD THE RIGHT SIDE TRUNK MOLDING (1B) ON.
2. REMOVE THE TWO SCREWS (1C) THAT HOLD THE LEFT SIDE TRUNK MOLDING (1D) ON.
3. REMOVE THE TWO SCREWS (1E) THAT HOLD THE CENTER TRUNK MOLDING (1F) ON.
4. INSTALL THE NEW CHROME MOLDING IN THE REVERSE OF REMOVAL.

