

CHROME RADIO KNOB INSTALLATION

INSTALLATION:

1. REMOVE OEM RADIO KNOB BY PULLING IT OFF.
2. USING A PLIER REMOVE THE OEM METAL CLIP FROM THE INSIDE OF THE OEM RADIO KNOB.
3. TAKE THE CLIP YOU JUST REMOVED AND INSTALL IT IN THE HOLE ON THE NEW CHROME KNOB. MAKE SURE THE CLIP IS INSTALLED IN THE SAME DIRECTION AS WHEN YOU REMOVED IT FROM THE OEM KNOB.
4. LINE UP THE FLAT SIDE ON THE KNOB WITH THE FLAT SIDE ON THE RADIO SHAFT AND PUSH THE NEW KNOB INTO PLACE.
5. THE NEW KNOB SHOULD BE VERY TIGHT.

NOTE: IF YOU HAVE TROUBLE STARTING THE KNOB ON THE SHAFT, TRY ROUNDING OUT THE TOP OF THE METAL CLIP.