

BIG BIKE PARTS®

INSTALLATION INSTRUCTIONS

Copyright© 2005 by Big Bike Parts, Inc.™
No part of this instruction sheet may be
reproduced without the written permission
of Big Bike Parts, Inc.™

Brake Side Heel Rest Fits Honda
Part No. 52-711 GL1800 Gold Wing

Updated 2-16-05

TOOLS NEEDED: 5MM ALLEN WRENCH
6MM ALLEN WRENCH

1. USING A 6MM ALLEN WRENCH REMOVE THE TWO SCREWS HOLDING THE PEG MOUNTING BRACKET TO THE FRAME.
2. USING A 5MM ALLEN WRENCH INSTALL THE HEEL REST BRACKET TO THE FRAME WHERE THE ORIGINAL SCREWS WERE PREVIOUSLY LOCATED WITH THE USE OF THE TWO M8 X 1.25 X 35MM LONG SCREWS AND THE WASHERS PROVIDED.
3. USING THE 6MM ALLEN WRENCH AND ONE OF THE BOLTS REMOVED IN STEP 1, ASSEMBLE THE HEEL REST TO THE INSIDE OF THE HEEL REST BRACKET AND THE RESTRICTOR PLATE TO THE OUTSIDE OF THE HEEL REST BRACKET. THREAD THE BOLT IN FROM THE OUTSIDE.

NOTE: WE RECOMMEND USING LOCTITE ON ALL SCREWS.