

# BIG BIKE PARTS® INSTALLATION INSTRUCTIONS

Copyright© 2008 by Big Bike Parts, Inc. No part of this instruction sheet may be reproduced without the written permission of Big Bike Parts, Inc.

PART NO. 52-792

MARTINI SADDLEBAG LIGHT SET  
HONDA GL1800 GOLDWING

9/11/08

TOOLS NEEDED: PHILLIPS SCREWDRIVER, 8MM SOCKET, RUBBING ALCOHOL, 11/32" DRILL BIT AND DRILL

**NOTE: READ INSTRUCTIONS BEFORE PROCEEDING.**

INSTALLATION:

1. PLACE BIKE ON CENTER STAND.
2. DISCONNECT THE NEGATIVE BATTERY CABLE.
3. REMOVE THE THREE SCREWS (1A) THAT HOLD THE RIGHT SIDE SADDLEBAG LID MOLDING (1B) ON.
4. REMOVE THE TWO SCREWS (1C) THAT HOLD THE RIGHT SIDE SADDLEBAG CORNER MOLDING (1D) ON. THERE IS ALSO ADHESIVE TAPE (1E) HOLDING THE CORNER PIECE ON.
5. WITH AN 11/32" BIT DRILL A HOLE (1G) IN THE CAVITY OF THE CORNER MOLDING FOR WIRE ROUTING.
6. WITH RUBBING ALCOHOL CLEAN THE AREA WHERE THE TAPE FROM THE MOLDING CONTACTS.
7. RUN THE PLUG AND WIRES THROUGH THE DRILLED HOLE. REMOVE THE TAPE BACKING AND PLACE THE NEW SADDLEBAG CORNER MOLDING INTO PLACE AND TIGHTEN DOWN WITH SCREWS (1C). APPLY PRESSURE TO THE AREA WHERE THE TAPE MAKES CONTACT FOR ONE MINUTE.
8. REMOVE THE SCREW HOLDING THE SADDLEBAG LID STRUT TO THE BOTTOM STRUT BRACKET. REMOVE THE STRUT BRACKET. THEN REMOVE THE SCREW AT THE FRONT OF THE SADDLEBAG LID ATTACHING THE SADDLEBAG LID SUPPORT CABLE TO THE SADDLEBAG LID.
9. DRILL AN 11/32" HOLE (1H) IN THE SADDLEBAG AT THE BOTTOM NEAR WHERE THE LID AND SADDLEBAG MEET BELOW THE SADDLEBAG LID STRUT TO ALLOW THE PLUG TO BE RUN INTO THE SADDLEBAG.
10. RUN THE PLUG AND WIRES THROUGH THE GAP WHERE THE BOTTOM STRUT BRACKET WAS.
11. REINSTALL THE BOTTOM STRUT BRACKET AND REATTACH THE SADDLEBAG LID STRUT. THEN REINSTALL THE SADDLEBAG LID SUPPORT CABLE TO THE SADDLEBAG LID.
12. PLACE THE NEW SADDLEBAG LID MOLDING INTO PLACE AND TIGHTEN DOWN THE SCREWS (1A).
13. RUN THE PLUG THROUGH THE HOLE DRILLED AND INTO THE SADDLEBAG.
14. USING AN 8MM SOCKET WRENCH REMOVE THE THREE NUTS HOLDING THE SADDLEBAG LIGHT (1F) TO SADDLEBAG. THE NUTS ARE ON THE INSIDE OF SADDLEBAG. THIS WILL ALLOW YOU TO ACCESS THE WIRES TO PLUG INTO.
15. WITH THE SADDLEBAG LIGHT REMOVED, TAKE THE THREE PIN PLUG HARNESS AND PLUG IT BETWEEN THE RUNNING/BRAKE BULB SOCKET AND THE OEM PLUG.
16. LOCATE THE LARGE RUBBER GROMMET ON THE INSIDE WALL OF THE SADDLEBAG LIGHT CAVITY. REMOVE THE GROMMET AND CUT A SLIT IN THE BOTTOM OF THE GROMMET. THIS WILL ALLOW YOU TO PUSH THE TWO BLUE PLUGS THROUGH. REINSTALL THE GROMMET AND PLUG THE FEMALE AND MALE BLUE PLUGS TOGETHER. TEST FOR OPERATION.
17. REPEAT STEPS 3-16 FOR OTHER SIDE.
18. REINSTALL ALL REMOVED PARTS.

