

BIG BIKE PARTS®

Copyright © 2005 by Big Bike Parts, Inc.
No part of this instruction sheet may be reproduced without the written permission of Big Bike Parts, Inc.

INSTALLATION INSTRUCTIONS SADDLEBAG STAYS FOR SPIRIT 1100C '99-05 PART NO. 53-125

TOOLS NEEDED: 5MM ALLEN WRENCH 12MM SOCKET 14MM SOCKET

1. USING 14MM SOCKET, REMOVE THE BOLT AT FRONT OF FENDER STRUT.
2. USING 12MM SOCKET, REMOVE BOLT AT REAR OF FENDER STRUT.
3. USING 10MM BOLT PROVIDED AT FRONT OF FENDER STRUT AND 8MM BOLT PROVIDED AT REAR OF FENDER STRUT, INSTALL THE SADDLEBAG STAY.
4. REPEAT STEPS 1 THROUGH 3 FOR OTHER SIDE.