

BIG BIKE PARTS® INSTALLATION INSTRUCTIONS

Copyright© 2006 by Big Bike Parts, Inc. No part of this instruction sheet may be reproduced without the written permission of Big Bike Parts, Inc.

PART NO. 71-125

STEPPED REAR CALIPER COVER
FOR KAWASAKI VN2000

TOOLS NEEDED: 8MM ALLEN WRENCH

1. WITH AN 8MM ALLEN WRENCH, REMOVE BOTH SOCKET HEAD CAP SCREWS WHICH ATTACH THE BRAKE CALIPER TO THE MOUNTING BRACKET.
2. INSERT ONE SPACER INTO EACH COUNTER BORE WHERE THE OEM HARDWARE WAS REMOVED FROM.
3. PLACE STEPPED REAR CALIPER COVER OVER THE BRAKE CALIPER, ALIGNING THE HOLES IN THE CALIPER COVER WITH THE HOLES IN THE MOUNTING BRACKET.
4. INSTALL ONE OF THE PROVIDED SOCKET HEAD CAP SCREWS IN EACH HOLE AND TIGHTEN DOWN TO MANUFACTURERS SPECIFICATIONS WITH AN 8MM ALLEN WRENCH.