

# **BIG BIKE PARTS®** INSTALLATION INSTRUCTIONS

Copyright© 2006 by Big Bike Parts, Inc. No part of this instruction sheet may be reproduced without the written permission of Big Bike Parts, Inc.

PART NO. 71-128

ABS NECK COVERS  
VN1600 CLASSIC & NOMAD

TOOLS NEEDED: 4 MM ALLEN HEAD WRENCH

**NOTE: THE REMOVAL OF THE GAS TANK MAY BE NECESSARY TO ALLOW ACCESS TO THE NECK COVER SCREWS.**

1. USING THE 4MM ALLEN HEAD WRENCH, REMOVE THE TWO SCREWS FROM EACH NECK COVER AND REMOVE NECK COVERS.
2. INSTALL THE NEW NECK COVERS BY USING THE HARDWARE PROVIDED IN THE REVERSE ORDER OF REMOVAL.