

BIG BIKE PARTS® INSTALLATION INSTRUCTIONS

Copyright© 2008 by Big Bike Parts, Inc. No part of this instruction sheet may be reproduced without the written permission of Big Bike Parts, Inc.

PART NO. 82-213A

HIGHWAY BARS
SUZUKI C50/M50/VL800

8/18/2010

TOOLS NEEDED: 14MM WRENCH

NOTE: IT IS RECOMMENDED TO USE LOCTITE ON ALL BOLTS

1. REMOVE THE HOLE PLUG THAT IS IN THE FRAME TUBE BELOW THE NECK COVERS.
2. INSTALL THE HIGHWAY BARS TO THE FRAME USING THE M10 X 1.25 X 20MM LONG BOLTS PROVIDED. THE TOP BOLT GOES THROUGH THE HOLE THE PLUG WAS REMOVED FROM IN STEP 1. ON THE INSIDE OF THE FRAME THERE IS A THREADED STUD BEHIND THE FOOT PEG BRACKET. THIS IS WHERE THE BOTTOM BOLT WILL GO.
3. REPEAT STEPS 1-2 FOR THE OTHER SIDE.