

BIG BIKE PARTS® INSTALLATION INSTRUCTIONS

Copyright© 2010 by Big Bike Parts, Inc. No part of this instruction sheet may be reproduced without the written permission of Big Bike Parts, Inc.

PART NO. 82-234

CHROME SWITCH BOX HOUSING
FOR SUZUKI 2007-2008 C50, C90
2008 C109

11/18/10

82-234B - BRAKE SIDE SWITCH BOX

TOOLS NEEDED: #1 PHILLIPS HEAD SCREWDRIVER FLAT BLADE SCREW DRIVER NEEDLE NOSE PLIERS
 #2 PHILLIPS HEAD SCREWDRIVER

1. LOOSEN THE THROTTLE CABLES TO CREATE AS MUCH SLACK AS POSSIBLE IN THE THROTTLE HANDGRIP.
2. USE THE #2 PHILLIPS SCREWDRIVER TO REMOVE THE THREE SCREWS FROM THE BOTTOM OF THE SWITCH BOX ALLOWING THE THREE SECTIONS TO BE SEPARATED AND REMOVED FROM THE HANDLEBAR.
3. USE THE #1 PHILLIPS SCREWDRIVER TO REMOVE THE BRACKET HOLDING THE THROTTLE CABLES TO THE LOWER SECTION OF THE SWITCH BOX ASSEMBLY.
4. REMOVE THE THROTTLE CABLES FROM THE THROTTLE TUBE USING A NEEDLE NOSE PLIERS IF NECESSARY. PULL THE THROTTLE CABLES THROUGH THE MIDDLE SECTION OF THE SWITCH BOX.
5. USE THE #1 PHILLIPS SCREWDRIVER TO REMOVE THE PLASTIC WIRE CLAMP AND THE STARTER SWITCH FROM THE MIDDLE SECTION OF THE SWITCH BOX.
6. USE THE #1 PHILLIPS SCREWDRIVER TO REMOVE THE SHUTOFF SWITCH FROM THE TOP SECTION OF THE SWITCH BOX.
7. INSTALL COMPONENTS REMOVED FROM THE OEM SWITCH BOX IN STEPS #5 AND #6 INTO THE CHROME SWITCH BOX SECTIONS IN REVERSE ORDER AS REMOVED.
8. PASS THE THROTTLE CABLES THROUGH THE MIDDLE SECTION OF THE CHROME SWITCH BOX AND THEN REATTACH THEM TO THE THROTTLE TUBE IN REVERSE ORDER AS STEP #4. REATTACH THE THROTTLE CABLE BRACKET TO THE LOWER SECTION OF THE CHROME SWITCH BOX.
9. ASSEMBLE THE SWITCH BOX TO THE HANDLEBAR. BE SURE TO PROPERLY ROUTE THE WIRES INSIDE THE SWITCH BOX TO AVOID PINCHING THEM.
10. INSTALL THE THREE SCREWS REMOVED IN STEP #2 THAT HOLD THE SWITCH BOX TOGETHER AND TIGHTEN SECURELY.
11. READJUST THE THROTTLE CABLES TO THE CORRECT AMOUNT OF SLACK.

82-234C - CLUTCH SIDE SWITCH BOX

TOOLS NEEDED: #1 PHILLIPS HEAD SCREWDRIVER #2 PHILLIPS HEAD SCREWDRIVER FLAT BLADE SCREWDRIVER

1. USE THE #2 PHILLIPS SCREWDRIVER TO REMOVE THE TWO SCREWS FROM THE BOTTOM OF THE SWITCH BOX ALLOWING THE TWO HALVES TO BE SEPARATED AND REMOVED FROM THE HANDLEBAR.
2. USE THE #1 PHILLIPS SCREWDRIVER TO REMOVE THE PLASTIC WIRE CLAMP, THE TURN SIGNAL SWITCH, AND THE HORN BUTTON FROM THE BOTTOM HALF OF THE SWITCH BOX.
3. USE THE #1 PHILLIPS SCREWDRIVER TO REMOVE THE METAL WIRE BRACKET, THE PASS SWITCH, THE HAZARD SWITCH, AND THE HI/LOW BEAM SWITCH FROM THE TOP HALF OF THE SWITCH BOX.
4. INSTALL COMPONENTS REMOVED FROM THE BOTTOM HALF OF THE OEM SWITCH BOX IN STEP #2 INTO THE BOTTOM HALF OF THE CHROME SWITCH BOX IN REVERSE ORDER AS REMOVED.
5. INSTALL THE COMPONENTS REMOVED FROM THE TOP HALF OF THE OEM SWITCH BOX IN STEP #3 INTO THE TOP HALF OF THE CHROME SWITCH BOX IN REVERSE ORDER AS REMOVED.
6. REASSEMBLE THE TWO HALVES OF THE SWITCH BOX TO THE HANDLEBAR. BE SURE TO PROPERLY ROUTE THE WIRES INSIDE THE SWITCH BOX TO AVOID PINCHING THEM.
7. INSTALL THE TWO SCREWS REMOVED IN STEP #1 THAT HOLD THE SWITCH BOX HALVES TOGETHER AND TIGHTEN SECURELY.