

PLEASE READ THROUGH AND UNDERSTAND THESE INSTRUCTIONS BEFORE BEGINNING.

INSTALLATION:

1. USING THE T27 TORX DRIVER REMOVE THE THREE SCREWS HOLDING THE WINDSHIELD TO THE BIKES FAIRING.
2. REMOVE THE WINDSHIELD AND SET IT ASIDE.
3. USING THE SAME TORX DRIVER REMOVE THE FOUR SCREWS (TWO ON EACH SIDE) ON THE BACK SIDE OF THE FAIRING. SEE FIG 1 BELOW.
4. LIFT UP THE FAIRING FRONT AND UNPLUG THE HEADLIGHT.
5. USING A LINT FREE TOWEL AND RUBBING ALCOHOL CLEAN THE AREA OUTLINED ON THE FAIRING DUCT SHOWN IN FIG. 2. LET DRY.
6. REMOVE THE TWO PIECES OF MASKING FROM THE DOUBLE-SIDED TAPE ON THE CHROME VENT SCREEN.
7. SET THE VENT SCREEN IN PLACE ON THE FAIRING DUCT AS SHOWN IN FIG. 3.
8. APPLY PRESSURE TO THE AREAS WITH THE DOUBLE-SIDED TAPE.
9. RECONNECT THE HEADLIGHT AND ATTACH THE FAIRING FRONT. INSTALL THE WINDSHIELD.
10. LET THE DOUBLE-SIDED TAPE CURE FOR 24 HOURS BEFORE USING BIKE.

