

Copyright © 2018 by Big Bike Parts, Inc. No part of this instruction sheet may be reproduced without the written permission of Big Bike Parts, Inc.

PART NO. 41-309

PASSENGER ARMREST KIT

3/1/2018

FITMENT: CAN-AM SPYDER F3/F3S/F3T/F3LTD 2015-NEWER

TOOLS NEEDED: 2MM ALLEN WRENCH

3MM ALLEN WRENCH

6MM ALLEN WRENCH

PHILLIPS SCREWDRIVER

REMOVABLE THREAD LOCK

PLEASE READ THROUGH AND UNDERSTAND THESE INSTRUCTIONS BEFORE BEGINNING. ** USE REMOVABLE THREAD LOCK ON ALL FASTENERS**
ESTIMATED INSTALLATION TIME: 30 TO 45 MIN.

INSTALLATION:

1. REMOVE ALL OF THE ITEMS FROM THE BOX AND FIND THE LEFT AND RIGHT MOUNTS. USE FIG. 1 TO IDENTIFY LEFT MOUNT.
2. ASSEMBLE THE LEFT ARMREST TOGETHER AS SHOWN IN FIG. 1. DO NOT INSTALL THE CLAMP, M5 SCREWS, SET SCREWS, AND CAP YET.
3. REMOVE THE PASSENGER SEAT AND SET IT ASIDE.
4. OPEN THE LEFT SADDLEBAG LID AND USING A 6MM ALLEN WRENCH REMOVE THE TWO BOLTS SHOWN IN FIG. 2.
5. REMOVE THE BOLTS AND SPACERS. NOTE THE POSITION OF ANY WASHER AS YOU REMOVE THE BOLTS. THE REAR SPACER WILL NOT BE REUSED.
6. PLACE THE LEFT ARMREST MOUNT ONTO THE LEFT PASSENGER HANDLE AS SHOWN IN FIG. 3.
7. TURN THE LEFT PASSENGER HANDLE OVER AND INSTALL THE CLAMP AND TWO M5 SCREWS AS SHOWN IN FIG. 4.
8. REINSTALL THE LEFT PASSENGER HANDLE IN REVERSE ORDER USING ALL OF THE OEM HARDWARE EXCEPT THE REAR SPACER AND TIGHTEN.
9. REPEAT STEPS 2 THROUGH 8 FOR THE RIGHT SIDE ARMREST.
10. TO ADJUST EACH ARMREST USE A 6MM ALLEN WRENCH TO TIGHTEN THE PIVOT BOLT.
11. USE THE 6MM ALLEN WRENCH TO HOLD THE PIVOT BOLT FROM MOVING AND INSTALL BOTH SET SCREWS AND TIGHTEN.
12. INSTALL THE CAPS WHEN ARMREST ARE AS DESIRED.
13. CLOSE THE SADDLEBAG LIDS AND REINSTALL THE PASSENGER SEAT.

