

## VERTICAL AIR INTAKE TRIM INSTALLATION

PLEASE READ AND UNDERSTAND THESE INSTRUCTIONS BEFORE BEGINNING.

TOOLS NEEDED: RUBBING ALCOHOL, CLEAN TOWEL, MASKING TAPE

### **INSTALLATION:**

1. STARTING ON THE RIGHT SIDE HOLD THE INTAKE TRIM IN PLACE WITH THE PVC MASKING STILL ATTACHED.
2. USE THE ROUND LOCATORS ON THE BACK OF THE TRIM TO FIND THE CORRECT POSITION.
3. USE 2 SMALL PIECES OF MASKING TAPE TO MARK THE LOCATION OF THE TRIM.
4. CLEAN THE AREA WITH RUBBING ALCOHOL AND LET DRY.
5. REMOVE PVC MASKING FROM TRIM AND USING THE MASKING TAPE PIECES AS A GUIDE INSTALL THE TRIM IN PLACE.
6. REMOVE MASKING TAPE.
7. REPEAT ON LEFT SIDE
8. LET FOAM TAPE CURE FOR 24 HOURS BEFORE USING BIKE.

Scan code  
with your  
smartphone  
to view video

