



Copyright© 2022 by Big Bike Parts, Inc. No part of this instruction sheet may be reproduced without the written permission of Big Bike Parts, Inc.

REVISED 9/9/2022

INSTALLATION INSTRUCTIONS

PART NO. 44-100

TURN SIGNAL LEVER EXTENDER

FITMENT: POLARIS SLINGSHOT 2015-NEWER

INCLUDED:

Turn Signal Lever
Extender

3M Double-Sided
Tape

TOOLS NEEDED:

Rubbing Alcohol

Lint Free Towel

PLEASE READ THROUGH AND UNDERSTAND THESE INSTRUCTIONS BEFORE BEGINNING.

ESTIMATED INSTALLATION TIME: 10 TO 15 MIN.

INSTALLATION:

1. USE RUBBING ALCOHOL TO PREP INSIDE SURFACE OF TURN SIGNAL LEVER EXTENDER (**FIG 1**) AND THE FRONT SIDE OF THE TURN SIGNAL LEVER (**FIG 2**). ALLOW SURFACES TO COMPLETELY DRY.
2. REMOVE ONE SIDE OF THE PROTECTIVE FILM AND FIRMLY APPLY TAPE TO THE INSIDE SURFACE OF THE TURN SIGNAL LEVER EXTENDER (**FIG 3**).
3. REMOVE THE SECOND SIDE OF THE PROTECTIVE FILM FROM THE TAPE MAKING SURE TO NOT PULL THE TAPE AWAY FROM THE TURN SIGNAL LEVER EXTENDER.
4. INSTALL TURN SIGNAL LEVER EXTENDER FROM NARROW END OF THE TURN SIGNAL LEVER MAKING SURE NOT TO TOUCH THE TAPE TO THE TURN SIGNAL LEVER (**FIG 4**). SLOWLY WORK THE TURN SIGNAL LEVER EXTENDER TOWARD THE END OF THE TURN SIGNAL LEVER.
5. ONCE IN THE DESIRED LOCATION, MAKE SURE THAT THE TAPE COMES IN CONTACT WITH THE TURN SIGNAL LEVER. FIRMLY HOLD THE TURN SIGNAL LEVER EXTENDER TO THE TURN SIGNAL LEVER FOR 30 SECONDS TO ALLOW TAPE TO BOND WITH BOTH SURFACES (**FIG 5**).
6. **FIG 6** SHOWS THE TURN SIGNAL LEVER EXTENDER INSTALLED.

FIG 1




FIG 2




FIG 3




FIG 4




FIG 5




FIG 6



NOTICE

IGNORING THE CONTENTS OF THESE INSTRUCTIONS MAY AFFECT THE PRODUCT PERFORMANCE AND FUNCTIONALITY. NOT FOLLOWING THESE INSTRUCTION MAY CAUSE DAMAGE TO THE PRODUCT OR THE VEHICLE TO WHICH IT IS BEING ATTACHED.

NOTICE

THIS IS AN ADHESIVE BACKED PRODUCT. CAUTION MUST BE TAKEN DURING INSTALLATION TO PROPERLY POSITION FOR ONE TIME PLACEMENT. REPEAT TRIALS WILL RESULT IN FAILURE OF THE ADHESIVE.